

Dishwasher Rinse Aid Biobel 20 Liters

EAN: 8421427065533 FABRICANTE: JABONES BELTRAN



Biobel Dishwasher Rinse Aid is an eco-certified product for a shiny, dry, streak-free finish on your dishes.

DESCRIPTION

What is Biobel Dishwasher Rinse Aid and what is it for?

Biobel Dishwasher Rinse Aid is a product that provides a dry, shiny and streak-free finish on your dishes. It is compatible with all common dishwashers and does not leave chemical residues on your dishes. It is a product free of ingredients derived from petroleum, enzymes, genetically modified organisms, phosphates and substances that release chlorine.

Its action is based on reducing the surface tension in the dishes, which makes it easier for water to slide off and dishes to dry more quickly.

This dishwasher rinse aid is a natural detergent certified by ECOCERT Greenlife, which guarantees its ecological and sustainable origin.

What are the ingredients of Biobel Dishwasher Rinse Aid?

- >30% water;
- 15-30% vegetable alcohol;
- 5-15% citric acid
- <5% amphoteric surfactant of plant origin
- 100% of the ingredients are of natural origin

How do you use Biobel Dishwasher Rinse Aid?

Place in the corresponding compartment of the dishwasher, taking into account the dosing instructions of your machine. The product is automatically dispensed by the dishwasher in the previous washing phase.

